

IMPORTANT - PLEASE READ

Terms and Conditions of End-User License Agreement

The software upgrade program for model DN-X1500 provided herewith (the "Software") is proprietary to DENON, Ltd. ("DENON") and has been made available to you only in accordance with and subject to the terms and conditions of this License Agreement. By installing or using the Software, you will be confirming your acceptance of the Software and your agreement to be bound by all of the following terms and conditions, including, without limitation, the disclaimers which are a part thereof:

1. **Title.**
The Software is the property of DENON. No title or ownership therein or thereto is transferred to you hereunder. This License only provides you with certain prescribed rights to use the Software, subject always to the terms and conditions herein set forth. All rights in and to the Software are reserved by DENON.
2. **Limited Rights of Use.**
This License only allows you to use the Software for your own internal purposes and solely in connection with Denon's DN-X1500 DJ Mixer (the "Product").
3. **Non-Disclosure.**
You acknowledge that the Software is proprietary to and a trade secret of DENON, and you agree not to make or distribute copies of the Software or to transfer the Software electronically or otherwise to any other person. Without limiting the generality of the foregoing, you also agree:
 - (a) Not to transfer the Software from one computer to another or over a network.
 - (b) Not to decompile, reverse engineer, disassemble or modify the Software in any way or for any purpose.
 - (c) Not to resell, rent or otherwise transfer the Software to any other person.
 - (d) Not to create or distribute any derivative works based upon the Software or any part thereof.
4. **Limited Warranty.**
The Software has been provided to you free of charge and on an "AS IS" basis; provided, that, DENON's Limited Warranty shall continue to apply with respect to the Product after installation of the Software, subject to all of the terms and conditions of such Limited Warranty, including its duration based on the original date of purchase of the Product. **DENON makes no other warranty of any kind, express or implied, including, without limitation, any implied warranty of merchantability or fitness for particular purpose, with respect to the Software or the Product.** Without limiting the generality of the foregoing:
 - (a) DENON assumes no responsibility for and shall have no liability of any kind with respect to any problems encountered in conjunction with or arising out of the downloading of the Software, including, without limitation, problems resulting from any interruption that may have occurred while downloading the Software.
 - (b) Neither DENON nor any of its distributors shall be required to provide you with any technical support or services of any kind relating to the Software.
5. **No Consequential Damages.**
Neither DENON nor any of its distributors shall be liable for any indirect, special, incidental or consequential damages or losses of any kind incurred or arising out of or in connection with your downloading or use of the Software.
6. **Hold Harmless.**
You agree to release and hold harmless DENON and its distributors of and from any and all claims, demands, suits, proceedings, losses, damages, liabilities, costs and expenses (including attorneys' fees and disbursements) of any kind arising out of or relating to the Software or its use.
7. **Governing Law.**
The terms and conditions of this License Agreement shall be governed by and construed in accordance with the law of the State of Illinois. Any claims, actions or proceedings relating to this License Agreement or the enforcement hereof shall be brought in the courts of the State of Illinois or Federal courts located in the State of Illinois, and you waive any objection to the jurisdiction of such courts.
8. **Entire Agreement.**
The terms and conditions herein set forth constitute the entire agreement between you and DENON with respect to the subject matter hereof, and all agreements, commitments, undertakings, understandings or statements of any kind previously made by DENON or any of its distributors with respect to the subject matter hereof are merged herein and superseded by this License Agreement. No amendment or modification of the terms of this License Agreement shall be effective or binding on DENON unless it is made in writing and executed or published by DENON.



DENON DJ

DN-X1500 USB Driver & Plug-In Installation Guide

The following instructions will explain in detail on how to:

A) Install the necessary USB drivers & DLL Files for the Denon DJ DN-X1500 mixer.

B) Install and Run the Software Plug-In.

Note:

*For PC only. (Mac is not supported)

*You will need a standard USB cable that fits the DN-X1500 port


USB Driver Installation:

Note:

*The USB Driver & DLL files must be installed before running the VersionUP Plug-In Software!!!

Step 1. Turn the power OFF

Step 2. Hold down the following 3 buttons on the mixer and then turn the power ON.
(Main Mic + Aux Mic + Talkover)



Step 3. The display will say "Version Up", if not repeat above Step 2 again.




Step 4. Connect the USB cable to the DN-X1500




DENON DJ

Step 5. Connect the other end of the USB cable to your computer




Step 6. Your computer should prompt you to "Found New Hardware Wizard"



Step 7. Select "Install from a list or specific location" (Advanced), then click "Next"




Step 8. Click on "Include this location in the search", and then click on "Browse" (Note: Make sure to delete any existing path shown, (ex. C:\Drivers\SonyUSB). Highlight it and then press delete before you click on "Browse".)




DENON DJ

Step 9. Click on Local Disk "C:\\" drive


Step 10. Locate the folder labeled "DNX1500", click on the folder so that it is highlighted. Then Click "OK"



Step 12. Now Click on the "Next" button to continue.



Step 13. The USB Driver should start to load




DENON DJ


Step 14. Some machines will detect the driver as not being certified by Microsoft. Click on "Continue Anyway".



Step 15. The next screen will indicate that you have completed installing the USB Drivers. Click "Finish"



Step 16. When completed, you should receive the following message of success.



END USB Driver Installation, Continue to DLL File Installation.


DENON DJ

DLL File Installation:


Note:

*The DLL file must be installed before running the Plug-In Software!!!


Step 1. Go to your Local Disk "C:\DNX1500" Directory



Step 2a. For Windows NT/2000 users Select and Double Click on the "**DLL File for Win NT-2000.exe**" File.




Step 2b. For Windows XP/98 users Select and Double Click on the "**DLL File for Win XP-98.exe**" File.




DENON DJ

Step 3. Click "OK" to Start




Step 4. Click "Start" to extract the DLL File into the System Folder
(Note: Do Not Change "Extract To" Path)


(For Windows NT/2000)



(For Windows XP/98)



Step 5. All Files have been extracted, Click "OK".



END DLL Installation. Continue to the "Executing Plug-In Software"


DENON DJ

Executing the Plug-In Software

Note:

*At this point you should have already installed the USB Driver and the DLL Files


Step 1. Go to your Local Disk "C:\DNX1500" Directory



Step 2. Click on the "**VersionUP.exe**" file to Execute the Plug-In Software


(Note 1: Please make sure the USB is connected to both your PC and Mixer before you execute the program.)

(Note 2: Please make sure the DN-X1500 Mixer is in "Version Up" Mode as it is indicated in the display, see image below)





DENON DJ

Step 3. After you double click the "**VersionUP.exe**" you will see the following screen.




NOTE:

***You will receive the following error messages if you do not have the USB connected or the Mixer set to "Version Up" Mode.
(see USB Driver Installation Steps 1-3 to set your mixer to "Version Up" Mode.)**




***If you receive these messages, click "OK", then close the program.
*Verify your connections and your mixer, then restart the program.**

Step 4. Click on the Folder icon.(see below)




DENON DJ


Step 5. Select the "GEN6795.bin" file, and click "Open"



Step 6. When you have selected the file, you will see the following screen.




Step 7. Click on the "Denon Logo" icon (see below) to run the program.




DENON DJ


Step 8. After clicking on the "Denon Logo" icon you will see the following, letting you know that the process has started.



Step 9. The display on your DN-X1500 mixer will read "Now Writing" with a countdown timer (*starting at around 500*)



(Counting down example)




Step 10. When the counter reaches "0", the display will read "Finish"



DENON DJ

Step 11. The program will now display that all the data was transferred. (*see below*).



Step 12. You may now close the program.

Step 13. You may now power off the mixer and disconnect the USB cable from your pc and mixer.

END

***Enjoy the New Features listed Separately**

DENON DJ



DN-X1500 New Plug Ins

1. Rear output trim adjustment no longer affects the Master Level meters
2. Stereo/Mono switch no longer affects the global cuing system
3. When all faders and gains are set to zero, the output is completely muted
4. Cross Fader response time was greatly improved
5. Channel Fader "Sharp" contour preset was made even sharper
6. Filter 2 now corresponds to DRY/WET control
7. Echo 1 now locks the BPM from changing during WET status and the TAP button now flashes
8. When TAP is selected once to lock the BPM, the TAP button now flashes
9. When BPM effects are turned ON, they are now synced to start at the beginning of the sine wave
10. When SPLIT/CUE is selected, the Master Cue is now ganged together to turn on
11. Master CUE can now be monitored pre master volume

[New version # will be:](#) (Sys6795/Dsp1020)

You may verify your software version number in the Preset mode.